Congratulations on your choice of TPS-MR1 AM/FM Bluetooth Source Unit by Hifonics. For more detailed information about the product, please visit our website at www.Hifonics.com




## CAUTION




Always consider consulting a professional audio installer before installing any audio components. Be careful and take your time. Do not let wires make contact with metal edges or hot engine components.


## Wiring




# **U-Bracket Mounting**



## **Direct Screw-Type Mounting**



- 1. Use a small flat head screw driver under the edge of the button door and apply upward pressure until the button panel's clips release and it lifts up.
- 2. Pull door away from the radio until it is detached from the radios face plate.
- 3. Position the radio in the location that is desired.
- 4. Use the screws included and screw the unit in place.
- 5. Reinstall the button doors.



## **Controls**

- Power On / Off / MUTE The power button is a multi-function button, depending on how long you hold the button. One Quick press of the power button when the unit is off, will turn it on. One Quick press of the power button when the unit is on will mute the output. Press and hold turns power off.
- Audio Mode Press the button quickly, to see show 'SEL' on the screen. Then with quick presses scroll through each of the audio functions: BASS, TRE, BAL, FAD, LOUD, EQ, BEEP, and regional radio settings (PREA EUR/USA) under FM/AM mode. Each function is adjusted using the # 5 button VOL Up/Down. The audible "BEEP" mentioned is disabled when using the RCA outputs. This is intentional to avoid damage to your speakers.
- **3** APS In FM or AM Mode, Press the button quickly to scan stored radio stations. Press and hold to automatically scan all stations programmed with a short audition of each. Press the button again to stop the scan.
- MOD This is your input mode switch. Press to scroll through your various inputs FM, BT, IPOD, USB, AUX1, and AUX2.
- WOL Volume Up / Down. Press quickly for small increments in volume, hold down for quicker adjustments.
- BND / Clock This multi-function button when pressed quickly, scrolls between your FM1, 2 and 3 plus AM1 and 2 banks for programmed stations.

  Press and hold button 6 to enter clock mode. Press button 6 once more to enter clock

adjust mode. Pressing it once more will toggle between hours and minutes. Use the Vol^ and Volv buttons to adjust the time.

RWD / Back – This multi-function button works with your music sources. In radio mode, quickly press to go back to the next strongest station.

For other sources, press quickly to go back to the beginning of the current song, press twice to go back to the beginning of the previous track. Press and hold for fast reverse within the current selection.

### **Controls**

- WD / Forward This multi-function button works with your music sources. In radio mode, quickly press to go forward to the next strongest station. For other sources, press quickly to go to the beginning of the next song. Press and hold for fast forward within the current selection.
- 1 Play / Pause This multi-function button works in several modes. For the BT, USB, Apple Device mode this is play and pause.
  In FM and AM mode quickly press to select station pre-set #1.

In radio mode press and hold to store the current station to this pre-set.

2 - INT / Intro – This multi-function button works in several modes. For the USB, press this to play the introduction (first 10 seconds) of each track. Press again to turn off the

In FM and AM mode quickly press to select station pre-set #2.

In radio mode press and hold to store the current station to this pre-set.

3 - RPT / Repeat – This multi-function button works in several modes. For the USB, press this button to repeat the current song. Press again to turn off the feature. (not compatible in iPod mode)

In FM and AM mode quickly press to select station pre-set #3.

In radio mode press and hold to store the current station to this pre-set.

4 - RDM / Random – This multi-function button works in several modes. For the USB, press this button allow random songs to play from that unit. The RDM will not select random tracks from different devices, only from the unit selected. (not compatible in iPod mode)

In FM and AM mode quickly press to select station pre-set #4.

In radio mode press and hold to store the current station to this pre-set.

## **Bluetooth Device Pairing**

feature. (not compatible in iPod mode)

The pairing process can vary based on your particular device. Refer to the operating instructions of your device. Below is the general process to connect.

Under the Bluetooth mode, the status indicator will flash slowly "BT music"and search for the last paired device. If no device is located, it will flash quickly indicating it is ready to pair to a new device.

On your Bluetooth enabled device, search for "HIFONICS" under Bluetooth settings.

Select HIFONICS, wait for the device to indicate "CONN OK."

Music will now play through the system.

To connect to a different device while currently paired, press and hold the PLAY/PAUSE button. This will initialize pairing mode.

#### WARRANTY

Maxxsonics USA Inc. warrants this product, to the original consumer purchaser, to be free from defects in material and workmanship for a period of one (1) year from the date of purchase. Maxxsonics USA Inc. will, at it's discretion, repair or replace defective products during the warranty period. Components that prove to be defective in materials and workmanship under proper installation and use must be returned to the original authorized Maxxsonics USA Inc. retailer from where it was purchased. A photocopy of the original receipt must accompany the product being returned. The costs associated with removal, re-installation and freight are not the responsibility of Maxxsonics USA Inc. This warranty is limited to defective parts and specifically excludes any incidental or consequential damages connected therewith. To view the full warranty, please visit the website.

#### FCC Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the
- -Consult the dealer or an experienced radio/TV technician for help.


WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complied with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.





# **Operators Guide**



TPS-MR1