


Cobra**AirWave**[®] Mini Speaker




CWA BT300 Product Information Guide



IMPORTANT

To get the full capability of your new Cobra Airwave® Mini, please read this manual. It's more than just a **Bluetooth®** Speaker!



CARE AND MAINTENANCE

1. Never try to disassemble or service the product by yourself.
2. Keep the Cobra Airwave® Mini and accessories out of reach from children.
3. Do not expose the Cobra Airwave® Mini to temperatures above +55 deg C (+131 deg F). If the product is operated in extreme hot or cold temperature, the battery capacity is reduced. Use it at room temperature for maximum battery capacity.

CHARGING


The Cobra Airwave® Mini has a built-in Li-ion battery (3.7V, 1600 mAh), so it can be used without connecting to a power supply. To charge the battery, follow these steps:

1. Connect the micro USB connector to the Cobra Airwave® Mini micro-USB input.
2. Plug the USB full-size connector into the micro-USB input. A common USB type AC charger (DC 5V, 500mA) or any USB power source.

- When the device is charging the LED status indicator will be RED. When fully charged the RED status indicator LED will go off.
- A full charge will last for up to 12 hours of normal use.

OPERATION

Turning the Cobra Airwave® Mini On or Off



Multi-Button

Press and hold the Multi-Button for 3 seconds to turn On. The blue LED will turn on and blink. Press and hold the Multi-Button for 5 seconds to turn Off. The red LED will turn on then turn off.

Pairing the Cobra Airwave® Mini with a smartphone or any Bluetooth® enabled music device


To use the Cobra Airwave® Mini with any **Bluetooth®** enabled smartphone or media device, you must first pair the device to the Cobra Airwave® Mini. Once they have been paired for the first time, the phone or media device will automatically re-connect to the Cobra Airwave® Mini when the power is turned ON and **Bluetooth®** is enabled on your device. For additional information, see the operation manual for your smartphone or media device.

Connecting with smartphone

1. Turn **Bluetooth®** on in your settings menu. It will begin searching for any **Bluetooth®** device within range.
2. With power off, press and hold the Multi-Button for 7 seconds until a double-beep sounds and the blue and red LEDs will alternately blink.
3. You will see the Cobra Airwave® Mini on the devices list on your phone. Select the **Cobra Airwave Mini** to pair. A single beep will sound and "**Connected**" will appear in the device's screen. Once connected, the blue LED light will blink on the device.

ADJUSTING VOLUME

To adjust the Cobra Airwave® Mini volume, press on the "+" or "-" buttons to increase or decrease volume.



- Volume can be adjusted with Cobra Airwave® Mini controls or the paired Bluetooth® device connected to the Cobra AirWave® Mini.

Pairing a new device with the Cobra Airwave® Mini

1. Use the smartphone or paired devices' BT settings to unpair the BT 300 Mini.
2. Turn on BT/scan with a different device.
3. Connect with new device and play.

Answer/hang up/place a call

If a call comes through in Stand By mode or while playing music, click on Multi-Button to answer the call. To hang up, press the Multi-Button again.

FCC & INDUSTRY CANADA STATEMENT

For Products Purchased in USA:

NOTE: This device complies with part 15 of FCC rules: Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received including interference that may cause undesired operation.



CAUTION: Modifications or parts not approved by Cobra Electronics Corporation may violate FCC Rules and void authority to operate this equipment.

For Products Purchased in Canada:

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device complies with Part 15 of the FCC Rules and with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

This equipment is portable device. The output power of this device is less than 20mW. The SAR test is not required.

FCC & INDUSTRY CANADA STATEMENT

continued

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Trademark Statement

Airwave®, Cobra® and the snake design are registered trademarks of Cobra Electronics Corporation, USA. Cobra Electronics Corporation™ is a trademark of Cobra Electronics Corporation, USA.

iPhone®, iPod® touch and Siri® are trademarks of Apple, Inc, registered with the U.S. and other countries.

Samsung S Voice® is a registered trademark of Samsung Electronics Company, LTD.

The **Bluetooth®** word mark is a registered trademark owned by Bluetooth SIG, Inc. and any use of such marks by Cobra Electronics Corporation is under license.

PRODUCT SERVICE QUESTIONS

For any questions about operating or installing this new Cobra product, or if parts are missing...**PLEASE CALL COBRA FIRST...** do not return this product to the store.

For Products Purchased in the U.S.A.

If your product should require factory service, please call Cobra first before sending your radio. This will ensure the fastest turn-around time on your repair. You may be asked to send your radio to the Cobra factory. It will be necessary to furnish the following to have the product serviced and returned.

- 1) For warranty repair include a copy of the original sales receipt. If you send the original receipt, it cannot be returned.
- 2) Send the entire product.
- 3) Enclose a detailed description of the problem along with the name and address of where the product is to be returned.
- 4) Pack radio securely to prevent damage in transit. If possible, use the original packing material.
- 5) Ship prepaid and insured by way of a traceable carrier such as United Parcel Service (UPS) or Priority Mail to avoid loss in transit to Cobra Factory Service:
Cobra Electronics Corporation
6500 West Cortland Street
Chicago, Illinois 60707 U.S.A.
- 6) If the radio is under warranty, it will be repaired or exchanged depending on the model.

Please allow approximately three to four weeks before contacting Cobra for status. If the product is out of warranty, a letter will automatically be sent informing you of the repair charge or replacement charge. If you have any questions, please call **800-262-7212** for assistance.

For Products Purchased Outside the U.S.A.

Please contact your local dealer for product service information.

LIMITED ONE-YEAR WARRANTY

For Products Purchased in the U.S.A.

Cobra Electronics Corporation warrants that its products and the component parts thereof, will be free of defects in workmanship and materials for a period of one year from the date of first consumer purchase. This warranty may be enforced by the first consumer purchaser, provided that the product is utilized within the U.S.A.

Cobra will, without charge, repair or replace, at its option, defective products, products or component parts upon delivery to the Cobra Factory Service department, accompanied by proof of the date of first consumer purchase, such as a duplicated copy of a sales receipt.

You must pay any initial shipping charges required to ship the product for warranty service, but the return charges will be at Cobra's expense, if the product is repaired or replaced under warranty. This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state.

Exclusions: This limited warranty does not apply: 1) To any product damaged by accident; 2) In the event of misuse or abuse of the product or as a result of unauthorized alterations or repairs; 3) If the serial number has been altered, defaced, or removed; 4) If the owner of the product resides outside the U.S.A.

All implied warranties, including warranties of merchantability and fitness for a particular purpose are limited in duration to the length of this warranty. Cobra shall not be liable for any incidental, consequential or other damages; including, without limitation, damages resulting from loss of use or cost of installation.

Some states do not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you.

For Products Purchased Outside the U.S.A.

Please contact your local dealer for warranty information.

Quick Reference Guide

Mode	Controls	Action	Functions
Power Off	○	>3s	Turn Power On/Off
	○	>7s	Pair to BT
Music	○	Press	Play/Pause Music
	+	Press	Volume Up
	-	Press	Volume Down
Phone	○	Press	Answer Incoming Call
	+	Press	Volume Up
	-	Press	Volume Down
	○	Press	End Call